


WELCOME TO THE WORLD OF BARBEQUES GALORE OUTDOOR COOKING
INSTRUCTIONS FOR THE ASSEMBLY AND ENJOYMENT OF YOUR NEW TURBO DIGITAL DISPLAY PANEL

These instructions contain important information that needs to be followed for the assembly and use of your new TURBO digital display panel. Please read through carefully and completely prior to assembly.

Tools required: Phillips head screw driver



Code: TBDIGDPQ

Disconnect the barbeque transformer from the power supply before proceeding with assembly.


Take extra care around sharp edges inside the control panel during assembly.

ASSEMBLY INSTRUCTIONS

Step 1. Remove the glass cover assembly on the barbeque control panel.


Remove the two screws on the side of the bbq control panel to remove the glass cover.

Keep those two screws, you will need them for step 4.



Step 2. Remove the bracket from the glass cover assembly.


Remove the two screws to separate the bracket from the glass cover assembly.




Note: Store the glass cover somewhere safe and dry in case required later.

Step 3. Connect the wiring.


a. Connect the display panel probe loom to the barbecue probe loom. Push together until the connection locks.




Note: Before fitting in the digital display panel into place, make sure the power supply wiring and hood temperature probe wiring extend down to the separation panel under the BBQ firebox.




b. Slide in the digital display panel into place in the cavity.



Step 4. Attach the bracket to lock the digital display panel. Use the two screws from Step 1.



Step 5. Connect the power supply and cooking temperature probe wiring.



Step 6. Connect the barbecue transformer to the power supply.

USING YOUR TEMPERATURE DIGITAL DISPLAY

INTERFACE INTRODUCTION



1. Master button

The master button on the bottom left of the display panel has two functions:

1. When the button is pressed once it will turn the temperature digital display ON/OFF .
2. When pressed and held for over 2 seconds, the temperature display will switch between Fahrenheit and Celsius.

2. Cooking temperature display

This reading tells you the ambient air temperature inside the BBQ. It is **NOT** the temperature of the cooking surface.

This digital reading shows the approximate air temperature your bbq will reach with the hood closed at the current burner settings. The analogue gauge at the front of the hood indicates the current air temperature at the front of the hood.

3. Meat probe temperature display

These numbers display the temperature reading for each of the 4 wired meat probes when they are connected to the BBQ.

CARE AND MAINTENANCE

- Minimise exposure of the digital display to the elements. Keep the barbeque covered once it has cooled down and not in use.
- Disconnect from the power supply when the barbeque is not in use for extended periods.
- Clean with a moist cloth. Avoid harsh cleansers.

WARRANTY AND CONSUMER GUARANTEE

The BBQ's Galore Warranty and consumer guarantees set out in this document override all other warranties on this product.

Barbeques Galore Warranty is provided in addition to other rights and remedies as set out below under 'Consumer Guarantees'.

Warranty Term

Subject to the conditions set out below, this product is warranted to the purchaser to be free from defects in workmanship and materials from the date of purchase for the terms specified below.

2 YEARS – Digital display unit

1 YEAR – Probes

Warranty Conditions

1. Barbeques Galore warranty is non transferable and is limited to the original purchaser.
2. Satisfactory proof of the purchase (as defined in the Competition and Consumer Act 2010 (CCA)) must be furnished at the time of notification of the defect for a claim under this warranty to be enforceable.
3. This warranty covers all parts found to be defective in workmanship and/or materials during the warranty period. Barbeques Galore total liability in respect of a claim by a consumer under the CCA for a minor problem (as defined in the CCA) with a product is limited, at our option, to providing the consumer with a refund, replacement product or repairing the product.
4. For major failures (as the term is defined in the CCA) you are entitled to a replacement or refund and for compensation for any other reasonably foreseeable loss or damage.
5. To implement this warranty, please return the product to the place of purchase or nominated service agent, otherwise a service call out fee will be charged and refunded if claim is warrantable.

Installation Conditions

All installations must conform to the applicable Gas, Electrical and Building standards as laid down by the local codes for state or region.

Warranty Exclusions

1. This warranty will be void and accordingly no claim of any nature will be enforceable if the product has not been assembled, installed or operated according to the instructions, or has been subject to abuse, improperly treated, neglected and/or if any repairs, maintenance or service has been done by an unauthorised person.

2. This warranty does not cover

- rust due to improper care or lack of maintenance. Contact your place of purchase for care and maintenance instructions
- commercial use
- claims arising from damage caused by abrasive chemical cleaners, heat discoloration or fat fires

Consumer Guarantee

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also

entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Subject to the above paragraphs, all express or implied representations, conditions, statutory guarantees, warranties and provisions (whether based on statute, common law or otherwise), relating to this warranty, that are not contained in it, are excluded to the fullest extent permitted by law.

Nothing in this warranty excludes, restricts or modifies any condition, warranty, statutory guarantee, right or remedy, implied or imposed by common law, statute or regulation, which cannot be lawfully excluded, restricted or modified.

For Customer Reference (keep these details filed in a safe place)

Purchased from

Date Purchased ____/____/____

Record Serial Number _____

N.B Satisfactory proof of purchase like your sales docket must be kept for any claim under this warranty to be enforceable.

Service Contact Point – Please contact your place of purchase for warranty repairs or service.

BRANCHES AUSTRALIA WIDE

Phone -1800 978 555 for your nearest store
CSR1@bbqgalore.com.au

Barbeques Galore Limited,
Build A2, Campus Business Park, 350-374
Parramatta Road, Homebush, NSW 2140
Phone 02 9735 4111

NEED MORE INFORMATION?

You can call your local Barbeques Galore store where barbeque experts will be happy to help you. Phone **1 800 978 555**
Or visit us online at:

www.barbequesgalore.com.au

For customer care call **1 300 139 867**

Scan this QR code for latest updates:



**BARBEQUES
GALORE**